

KODAK IMAGING INSTRUCTIONS

1. Make sure camera is turned on.
2. Open Kodak 1D software.
3. Select DC290 capture icon (top left or under File).
4. Select exposure time: Bright bands 1
Faint bands 3
Normal bands 2
5. Select image size
6. Saving your image

Method 1

- deselect Open Immediately
- click on Camera Pref: for Jpeg files select a compressed Image Resolution, for Tiff files select an uncompressed Image Resolution, click ok
- click on Export Image, choose location and name file
- open Jpeg (or Tiff) file in Kodak 1D, manipulate image and save as Kodak 1D file (**you must RENAME it or you will lose it**).
- Re-open Kodak 1D image and save as Jpeg or Tiff (again you need to RENAME it). This will save your manipulated image.

Method 2

- select Open Immediately
- Take Picture
- Save (automatically saves as a Kodak 1D file)
- Select "Save as", RENAME file (**you must rename it or you will lose it**), choose Jpeg or Tiff from the scroll down

7. DELETING THE KODAK 1D IMAGE

- after you have saved your image (manipulated or not) as a Jpeg or Tiff (either by Method 1 or Method 2) please DELETE the Kodak 1D image. These images are very large in size and will use up the computers memory at a very fast rate.
- **ALL IMAGES REMAINING ON THE HARD DRIVE AT 12:01 PM FRIDAY WILL BE DELETED. NO EXCEPTIONS!**

Contact: Melanie Lewis Ivey (Rm 231, ext 2704)